

ORFCAT18FULLV2 Sonor Orff Catalog.indd 1



# Welcome to Orff-World

Many years of experience, along with our passion for innovation and quality, have made our instruments an essential component of classrooms around the world – and have made SONOR the global market leader.

It all started in 1875 with a small drumhead workshop in Weißenfels an der Saale, Germany. Founded by the lathe turner and whittawer, Johannes Link, a flourishing business grew out of modest beginnings. By the turn of the century, an extensive variety of percussion instruments were being manufactured by the Link family.

Carl Orff and Gunild Keetman developed the Orff-Schulwerk method in the late 1940's. Their unique approach to elementary music and movement started to gain more popularity mainly due to the broadcasting of "Schulwerk programs" on Bavarian radio. The Links' foresight, along with their passion and vision for expanding the range of products, provided the inspiration for the development of SONOR Orff Instruments which were officially included in the production rangin 1953. This was the beginning of a new era.

The Links pioneered continuing musical education, from which groundbreaking, didactical concepts originated. They invested heavily in research & development, which produced many technological advancements, such as the sound bar material used in Palisono products and the invention of chime bars.

Our close, on-going collaboration with music educators and therapists is the foundation of our philosophy. We are focused on practice-based theory, and are committed to serving our customer base, as well as the professional community of which we are all a part.

We honor SONOR's reputation for tradition, innovation, quality and service by creating instruments that live up to your expectations, support your work in the best possible way, and . . . contributes to pleasurable music-making experiences!



Yours,









02 | 03 MALLET INSTRUMENTS



The idea that music begins inside human beings was the foundation of Carl Orff's approach to music education and is intended to inspire children to take part in *Elemental Music-Making*. Carl Orff (b. 1895) was particularly interested in the natural and vital aspects of music. For him, music was one of the most important means of expressing personality.



However, he was critical of the established music education of the time because it insisted that children perform existing songs without being allowed to develop their own creativity. He went on to collaborate with other musicians in the development of his Schulwerk, or approach, which combined music, rhythm and dance. He summarized his combination of these three elements in the term *Elemental Music Exercises*. Improvisation was always one key aspect of Orff's approach. He wanted to foster true spontaneity, the use of the imagination and creativity — the real principles of music. Decades after Carl Orff and Gunild Keetman developed the Orff Schulwerk in 1948, the approach is still valid.

Incorporating music, language, and movement stimulates children's creativity and imagination. The improvisation that occurs in the Orff classroom encourages children to find their own voice, resulting in self-confidence, and social development.

The nature of Orff's Schulwerk also offers an array of creative approaches for managing changes in society. The key principle is that *Elemental Music-Making is an easy-to-learn experience for everyone*. Playing Orff instruments is intuitive and easily accessible to everyone. Active participation in music-making fosters a feeling of inclusion among people of varying ages, languages and cultural backgrounds. In many respects, this communal experience takes precedence over the individual process of learning, allowing creativity and imagination to come before the musical score and technical exercises.









04|05 ORFF SERIES



# ORFF





# Meisterklasse


Meisterklasse is SONOR's largest range of instruments within the program for music education, therapy, leisure and family. Meisterklasse presents the ultimate in sound quality and craftsmanship. Although modern technology is firmly integrated into the manufacturing process, the secret of the SONOR sound lies in its continued dedication to detail and focus on excellent craftsmanship as established by SONOR's founder.

# **Special Features:**

- 6 octave chromatic tonal range, C to c5
- Special alloy metal bars and select rosewood bars
- Sound bars with overtone or fundamental tuning
- Resonator boxes with special acoustic chambers and brackets for carrying legs or the Basis Trolley system
- Surface protection of all wood finishes with "Proterra" (Euronorm EN 71-3)



All wood surfaces are protected with Proterra, an environmentally safe, all-natural varnish.




# Palisono

The Palisono Series consists of 65 xylophones and chime bars with Palisono bars. Palisono, a sound material developed by SONOR in cooperation with engineering specialists, contains special characteristics that are ideally suited for the manufacturing of xylophones. Made of high-density, humidity resistant fiberglass, Palisono bars ensure premium tonal quality and increased tuning stability throughout the range of instruments. The same manufacturing standards apply for Palisono as for all Meisterklasse instruments: Excellence in quality and craftsmanship.

### **Special Features:**

- $\bullet$  5 octave chromatic tonal range, C to b-flat4
- Sound bars with overtone or fundamental tuning
- Resonator boxes with brackets for carrying legs or for the Basis Trolley system
- Surface protection of all wood finishes with "Proterra" (Euronorm EN 71-3)









# Primary

The Primary Series is comprised of glockenspiels, xylophones, metallophones, chime bars, timpani and small percussion instruments. When we last revised the range, we attached great importance to the choice of materials used for their construction. We are proud to be able to offer you the first certified environmentally friendly Orff instruments. For many years, we have used Proterra consisting of shellac, oil and carnauba wax. We have been awarded FSC\* certification, which means the wood in our products originate from forests managed according to the highest standards. For more information on FSC Certification, please go to page 39 or visit www.fsc.org.

# **Special Features:**

- 6 octaves tonal range, C to a4
- 4 octaves are chromatic, c to b-flat3.
- The sound material of the xylophones is the beautifully veined and colorful African Pao Rosa.
- Sound bars with overtone tuning, fundamental tuning or standard tuning.
- Imprinted on all sound bars is the staff with the corresponding note.
- Resonator boxes with brackets for carrying legs or for the Basis Trolley system
- Surface protection of all wood finishes with "Proterra" (Euronorm EN 71-3)

# Global Beat

Global Beat consists of 2 glockenspiels, 6 xylophones and 3 metallophones.

This series is a great value with good sound and affordable pricing.

### **Special Features:**


- $\bullet$  Approx. 4 octaves diatonic range, c to a4
- Metal, Sucupira wood and fiberglass bars available
- Sound bars with overtone tuning, fundamental tuning or standard tuning.
- Each xylophone and metallophone has a bag to store the 3 accidentals lower f-sharp, b-flat and higher f-sharp.
- Surface protection of all wood finishes with "Proterra" (Euronorm EN 71-3)



All wood surfaces are protected with Proterra, an environmentally safe, all-natural varnish. (Euronorm EN 71-3)



All wood surfaces are protected with Proterra, an environmentally safe, all-natural varnish.
(Euronorm EN 71-3)



**FSC** 





06 | 07 GLOCKENSPIELS



# Meisterklasse Glockenspiels

The excellent sound and soft shape of the resonator boxes of these glockenspiels invite creative playing. The metal bars of the Meisterklasse glockenspiels are 20% wider.

# **Special Features:**

- Special alloy metal bars 25X5 mm with fundamental tuning
  Resonator boxes made of solid and laminated beechwood
  All wood surfaces are protected with Proterra, an environmentally safe, all-natural varnish.



**SG 25** 

- f-sharp4 and b-flat4

- 19 bars, c2-c4, 1 pair SCH 3 and SCH 95, C-major scale with f-sharp2, b-flat2, f-sharp3 and b-flat3



# Did you know?

Until the 17th century, glockenspiels were actually small bells that were struck with metal rods. This is where the name glockenspiel came from (Glocken in German means bells). From the late 17th century onwards, the small bells started to be replaced by little steel plates, developing into the glockenspiels that we know today. Wolfgang Amadeus Mozart was one of  $\,$ the first well-known composers to employ the glockenspiel professionally in an orchestra setting. He chose to use a glockenspiel to represent the bird catcher, Papageno in his famous opera, The Magic Flute (1791).



Primary Glockenspiels

The Primary glockenspiels SGP and AGP support music reading. The bars are printed with note names and staff positions to help players visually connect the sound of a note with its notation, especially when improvising self-created melodies. From the other perspective, players get a feeling of what a printed note sounds like.

### **Special Features**

- Silver steel sound bars, 20 x 3 mm in size, with fundamental tuning
- Resonator boxes made of pinewood, solid and plywood, surface protection
  of all wood finishes with "Proterra"



All wood surfaces are protected with Proterra an environmentally safe, all-natural varnish.

(Furonorm FN 71-3)

### Soprano

**SGP** 16 hars c3-a4 1 nair SCH 95

C-major scale with f-sharp3, b-flat3 and f-sharp4

### Alto


AGP 16 bars, c2-a3, 1 pair SCH 95, C-major scale with f-sharp2, b-flat2 and f-sharp3







# Global Beat Glockenspiels



### Soprano

GS GB 16 bars, c3-a4, 1 pair SCH 40, C-major scale with f-sharp3, b-flat3 and f-sharp4

### Alto

GA GP 16 bars, c2-a3, 1 pair SCH 40, C-major scale with f-sharp2, b-flat2 and f-sharp3












# Kinderglockenspiels



It was very important for us to develop a child friendly design for these glockenspiels without sacrificing quality of sound and materials. These specially designed glockenspiels are perfect to introduce early childhood sound concepts while providing an enriching musical experience that helps build auditory skills.



Our glockenspiels feature synthetic frames, rounded edges and integrated compartments for the mallets. Available bar color options include classic red, multi-color and a Boomwhackers® color-coordinated configuration.



### Soprano

**BWG** 

SG 13 bars, c3-f4, 1 pair SCH 40, C-major scale with f-sharp3 and b-flat3

GS Kinderglockenspiel, bars, c3-f4, 1 pair SCH 40, C-major scale, children's songs with colored notes

BWG Boomwhackers® Kinderglockenspiel, 13 bars, c3-f4, 1 pair SCH 40, C-major scale with f-sharp3 and b-flat3, nursery rhymes with colored notes





 $Boomwhackers \verb§§ is a registered trademark of Rhythm B and Instruments, LLC. \\$ 

Mama Mouse and her baby, Mini Mouse are popular with children because of their size and scale for young musicians to begin improvising. The Mini Mouse, with a pentatonic scale, ensures a pleasant sound experience regardless of note combinations played. With pentatonic tuning, improvisational skills are developed, ensuring all notes are aurally pleasant.





Mini Mouse glockenspiel, 5 bars, g3, a3, b3, d4, e4, G-major pentatonic

scale, 1 pair SCH 40S, children's songs with colored note heads

MG C Mouse glockenspiel, 8 bars, c3-c4, 1 pair SCH 40, C-major scale,

children's songs with colored notes

MaMa & MiMa Glockenspiel Set consisting of: Mama Mouse and Mini Mouse in a

beautifully finished wood case, children's songs with colored notes

**GP** 14 bars, c3-f-sharp4, 1 Paar SCH 40, C-major scale with f-sharp3,


b-flat3 and f-sharp4



AMA MAUS & MINI MAUS

MiMa









# Reference Glockenspiels


		Number of bars	Scale	Tonal range	
SOPRANO					
SG 19	Soprano Meisterklasse	19	C-major with f-sharp3, b-flat3, f-sharp4 and b-flat4	G-G	
SG 25	Soprano Meisterklasse	25	chromatic	<b>ც</b> -ც	
SGP	Soprano PRIMARY	16	C-major with f-sharp3, b-flat3 and f-sharp4	c3-a4	
GS GB	Soprano GLOBAL BEAT	16	C-major with f-sharp3, b-flat3 and f-sharp4	c3-a4	
NG 10	Soprano NG	13	C-major with f-sharp3 and b-flat3	c3-f4	
NG 30	Soprano NG	19	chromatic	c3-f#4	
SG	Soprano Kinderglockenspiel	13	C-major with f-sharp3 and b-flat3	c3-f4	
GS	Soprano Kinderglockenspiel	11	C-major	c3-f4	
BWG	Soprano Kinderglockenspiel	13	C-major with f-sharp3 and b-flat3	c3-f4	
GP	Soprano Kinderglockenspiel	14	C-major with f-sharp3, b-flat3 and f-sharp4	c3-f#4	
MG C	Soprano Mouse Glockenspiel	8	C-major	c3-c4	
MIMA	Soprano Mini Mouse Glockenspiel		G-major pentatonic	g3, a3, h3, d4, e4	
Alto					
AGP	Alto PRIMARY	16	C-major with f-sharp2, b-flat2 and f-sharp3	c2-a3	
NG 11	Alto NG	16	C-major with f-sharp2, b-flat2 and f-sharp3	c2-a3	
NG 31	Alto NG	23	chromatic	c2-b3	(
GA GB	Alto GLOBAL BEAT	16	C-major with f-sharp2, b-flat2 and f-sharp3	c2-a3	
TENOR-Alto		<u> </u>			
TAG 19	Tenor-Alto Meisterklasse	19	C-major with f-sharp2, b-flat2, f-sharp3 and b-flat3	c2-c4	
TAG 25	Tenor-Alto Meisterklasse	25	chromatic	c2-c4	







Bars (mm)	Tuning	Resonator Box Material	Mallet (1 pair)
aluminum 25 x 5	G	beechwood, solid and plywood	SCH 3 and SCH 95
aluminum 25 x 5	G	beechwood, solid and plywood	SCH 3 and SCH 95
steel 20 x 3	G	pinewood, solid and plywood	SCH 95
steel 20 x 3	G	pinewood, solid and plywood	SCH 40
steel 20 x 2	G	beechwood, solid and plywood	SCH 40
steel 20 x 2	G	beechwood, solid and plywood	SCH 40
steel 20 x 2	G	plastic with holder for mallet, f-sharp3, b-flat3	SCH 40
steel20 x 2	S	plastic with holder for mallet	SCH 40
steel 20 x 2	G	plastic with holder for mallet, f-sharp3, b-flat3	SCH 40
steel 20 x 2	S	beechwood, solid and plywood	SCH 40
steel 20 x 2	S	pinewood, solid	SCH 40
steel 20 x 2	S	pinewood, solid	SCH 40S
steel 20 x 3	G	pinewood, solid and plywood	SCH 95
steel 20 x 2	G	beechwood, solid and plywood	SCH 40
steel 20 x 2	G	beechwood, solid and plywood	SCH 40
steel 20 x 3	G	pinewood, solid	SCH 40
aluminum 25 x 5	G	beechwood, solid and plywood	SCH 3 and SCH 95
aluminum 25 x 5	G	beechwood, solid and plywood	SCH 3 and SCH 95



5/2/18 09:35



# Meisterklasse Xylophones

All wood surfaces are protected with Proterra, an environmentally safe, all-natural varnish. (Euronorm EN 71-3)

Meisterklasse xylophones have the highest quality rosewood bars with overtone tuning or fundamental tuning. All resonator boxes are equipped with brackets for carrying legs or the Basis Trolley system. Surface protection of all wood finishes and bars with "Proterra".

Soprano	)	Tenor-Al	to	Deep Ba	iss
SKX 10	16 bars, c2-a3, 1 pair SCH 16, C-major scale with f-sharp2, b-flat2 and f-sharp3	TAKX 10	19 bars, c1-c3, 1 pair SCH 16, C-major scale with f-sharp1, b-flat1, f-sharp2 and b-flat2	GBKX 10	16 bars, c-a1, 1 pair SCH 25, C-major scale with f-sharp, b-flat and f-sharp1
SKX 20	7 bars, sharp: c2, d2, g2, c3, d3, g3, flat: b3, chromatic extension for SKX 10	TAKX 20	7 bars, sharp: c1, d1, g1, c2, d2, g2, c3, chromatic extension for TAKX 10	GBKX 20	6 bars, sharp: c, d, g, c1, d1, g1, chromatic extension for GBKX 10
SKX 30	23 bars, c2-b-flat3, 1 pair SCH 16, chromatic scale combination of SKX 10 and SKX 20	TAKX 30	26 bars, c1-c-sharp3, 1 pair SCH 16, chromatic scale, combination of TAKX 10 and TAKX 20	GBKX 30	22 bars, c-a1, 1 pair SCH 25, chromatic scale, combination of GBKX 10 and GBKX 20
Lightwe the walk for indiv The sma	g-Xylophone ight and portable, king xylophone is perfect idual music therapy applications. Iller scale will easily fit on wheelchair r in your lap and makes it easy to engage		LWX 1	Sopran	
	and adults. It is also ideal as the lead instrument facilitation.			LWX 1	6 bars, c2, d2, e2, g2, a2, c3, 1 pair SCH 2,pentatonic starting with c, Sucupira (South American Hardwood) bars 35 x 18 mm, fundamental tuning, resonator made of pinewood, plywood, length 50 cm, width 15 cm, height 8.5 cm



These xylophones have Palisono fiberglass sound bars with overtone tuning or fundamental tuning. Their tuning is resistant to temperature fluctuations and humidity variations. All resonator boxes (except AX PO) are equipped with brackets for carrying legs or the Basis Trolley. Sound bars and resonator boxes are treated with environmentally safe "Proterra" finish.

Soprano		Tenor-Alto	Bass
SKX 100	16 bars, c2-a3, 1 pair SCH 11, C-major scale with f-sharp2, b-flat2 and f-sharp3	TAKX 100 19 bars, c1-c3, 1 pair SCH 11, C-major scale with f-sharp1, b-flat1, f-sharp2 and b-flat2	BKX 100 16 bars, f-c2, 1 pair SCH 25, C-major scale with f-sharp, b-flat, f-sharp1 and b-flat1
SKX 200	7 bars, sharp: c2, d2, g2, c3, d3, g3, flat: b3, chromatic extension for SKX 100	TAKX 200 7 bars, sharp: c1, d1, g1, c2, d2, g2, c3, chromatic extension for TAKX 100	BKX 200 5 bars, sharp: g, c1, d1, g1, c2, chromatic extension for BKX 100
SKX 300	23 bars, c2-b-flat3, 1 pair SCH 11, chromatic scale, combination of SKX 100 and SKX 200	TAKX 300 26 bars, c1-cis3, 1 pair SCH 11, chromatic scale, combination of TAKX 100 and TAKX 200	BKX 300 21 bars, f-c-sharp2, 1 pair SCH 25, chromatic scale combination of BKX 100 and BKX 200
Alto			
AX PO	16 bars, c1-a2, 1 pair SCH 11, C-major scale		Deep Bass
	with f-sharp1, b-flat1 and f-sharp2		GBKX 100 16 bars, c-a1, 1 pair SCH 25, C-major scale with f-sharp, b-flat and f-sharp1
	Ti de la companya de		GBKX 200 6 bars, sharp: c, d, g, c1, d1, g1, chromatic extension for GBKX 100
7	7		GBKX 300 22 bars, c-a1, 1 pair SCH 25, chromatic scale, combination of GBKX 100 and GBKX 200
0			
		11/1/17	



14 | 15 XYLOPHONES



CDVD 1

**AXP 1.1** 

**GBXP 2.1** 

# Primary Xylophones

# Primary – The future sounds green!

The bars, printed with note names and staff positions, help the player connect the sound of the note with its notation, which is helpful when improvising or playing self-created melodies. From the other perspective the players get a feeling of how a printed note sounds. All Primary xylophones have 35 x 18 mm Pao Rosa sound bars with overtone or fundamental tuning. The newly designed resonator box with enhanced acoustics are made of solid and laminated birch. The sound bars and resonator boxes of SONOR Primary xylophones are made of FSC\*\* certified timber from well managed forests. In addition, all wood surfaces are protected with Proterra, an environmentally safe, all-natural varnish.



The mark of



All wood surfaces are protected with Proterra, an environmentally safe, all-natural varnish.

(Euronorm EN 71-3)

**AXP 2.1** 

# Global Beat Xylophones

# **Xylophones with Sucupira Hardwood Sound Bars**

Hardwood sound bars are 35 x 18 mm with overtone tuning or fundamental tuning and resonator boxes made of birch plywood. Each xylophone is equipped with a carrying bag to stow 3 bars (2 x f-sharp, 1x b-flat)

### Soprano

SX GB 16 bars, c2-a3, 1 pair SCH 23, C-major scale with f-sharp2, b-flat2 and f-sharp3

### Alto

AX GB 16 bars, c1-a2, 1 pair SCH 23, C-major scale with f-sharp1, b-flat1 and f-sharp2

### Deep Bass

GBX GB 16 bars, c-a1, 1 pair SCH 25, C-major scale with f-sharp, b-flat and f-sharp1

SX GB



**GBX GB** 











SOPRANO		Number of Bars	Scale	Tonal Range
SKX 10	Soprano Meisterklasse	16	C-major with f-sharp2, b-flat2 and f-sharp3	c2-a3
			C-major with t-snarp2, b-flat2 and t-snarp3	
SKX 20	Soprano Meisterklasse	7	C	c*2, d*2, g*2, c*3, d*3, g*3, b <sup>b</sup> 3
SKX 100	Soprano Palisono	16	C-major with f-sharp2, b-flat2 and f-sharp3	c2-a3
SKX 200	Soprano Palisono	7		c <sup>#</sup> 2, d <sup>#</sup> 2, g <sup>#</sup> 2, c <sup>#</sup> 3, d <sup>#</sup> 3, g <sup>#</sup> 3, b <sup>b</sup> 3
SXP 1.1	Soprano Primary	16	C-major with f-sharp2, b-flat2 and f-sharp3	c2-a3
SXP 2.1	Soprano Primary	7		c <sup>#</sup> 2, d <sup>#</sup> 2, g <sup>#</sup> 2, c <sup>#</sup> 3, d <sup>#</sup> 3, g <sup>#</sup> 3, b <sup>b</sup> 3
SX GB	Soprano Global Beat	16	C-major with f-sharp2, b-flat2 and f-sharp3	c2-a3
SX GBF	Soprano Global Beat	16	C-major with f-sharp2, b-flat2 and f-sharp3	c2-a3
ALTO				
AXP 1.1	Alto Primary	16	C-major with f-sharp1, b-flat1 and f-sharp2	c1-a2
AXP 2.1	Alto Primary	7		c*1, d*1, g*1, c*2, d*2, g*2, b <sup>b</sup> 2
AX GB	Alto Global Beat	16	C-major with f-sharp1, b-flat1 and f-sharp2	c1-a2
AX GBF	Alto Global Beat	16	C-major with f-sharp1, b-flat1 and f-sharp2	c1-a2
AX PO	Alto Palisono	16	C-major with f-sharp1, b-flat1 and f-sharp2	c1-a2
TENOR-ALTO				
ГАКХ 10	Tenor-Alto Meisterklasse	19	C-major with f-sharp1, b-flat1 and f-sharp2	c1-c3
ГАКХ 20	Tenor-Alto Meisterklasse	7		c#1, d#1, g#1, c#2, d#2, g#2, c#3
ГАКХ 100	Tenor-Alto Palisono	19	C-major with f-sharp1, b-flat1 and f-sharp2	c1-c3
TAKX 200	Tenor-Alto Palisono	7		c*1, d*1, g*1, c*2, d*2, g*2, c*3
BASS				
BKX 100	Bass Palisono	16	C-major with f-sharp, b-flat, f-sharp1 and b-flat1	f-c2
BKX 200	Bass Palisono	5		g*, c*1, d*1, g*1, c*2
DEEP BASS				
GBKX 10	Deep Bass Meisterklasse	16	C-major with f-sharp, b-flat and f-sharp1	c-a1
GBKX 20	Deep Bass Meisterklasse	6		c*, d*, g*, c*1, d*1, g*1
GBKX 100	Deep Bass Palisono	16	C-major with f-sharp, b-flat and f-sharp1	c-a1
GBKX 200	Deep Bass Palisono	6		c*, d*, g*, c*1, d*1, g*1
GBXP 1.1	Deep Bass Primary	16	C-major with f-sharp, b-flat and f-sharp1	c-a1
GBXP 2.1	Deep Bass Primary	7		c#, d#, g#, c#1, d#1, g#1 , b <sup>b</sup> 1
GBX GB	Deep Bass Global Beat	16	C-major with f-sharp, b-flat and f-sharp1	c-a1
GBX GB F	Deep Bass Global Beat	16	C-major with f-sharp, b-flat and f-sharp1	c-a1
CX P	Concert Xylophone Rosewood*	38	chromatic	f-fis3
CX PO	Concert Xylophone Palisono*	38	chromatic	f-fis3
LWX 1	Walking-Xylophone	6	pentatonic starting with c	c2, d2, e2, g2, a2, c3
	1	1/2		





# Practice Tip: Using colored dots to make chord playing easier

A simple accompaniment to a song often consists of just a few chords. You will recognize these from the chord notation or guitar tabs above the lines of the score. With colorful adhesive dots, you can make it easier to accompany a song on the xylophone. As an example, we have used green, red and blue dots for the basic chords of the C-major scale. The colors help to create a better overview, and you can immediately tell which notes belong to the C-major scale and which to the F-major or G-major scales.

The same principle works with both metallophones and all chime bars. Some of our chime bars have already been marked with green, red and blue colors. Please refer to pages 29 for further details.



Chromatic Extension	Chromatic Instrument	Bars (mm)	Tuning	Resonator Chambers	Resonator Box Material	Mallets (1 Pair)
		Rosewood 37 x 18	G	3	pinewood	SCH 16
SKX 10	SKX 30	Rosewood 37 x 18	G	3	pinewood	
		Palisono 38 x 15	G	3	pinewood	SCH 11
SKX 100	SKX 300	Palisono 38 x 15	G	3	pinewood	
		Pao Rosa 37 x 18	G	1	birchwood	SCH 11
SXP 1.1	SXP 3.1	Pao Rosa 37 x 18	G	1	birchwood	
		Sucupira 37 x 18	G	1	birchwood	SCH 11
		Fiberglass 38 x 15	G	1	limewood	SCH 23
		Pao Rosa 37 x 18	G	1	birchwood	SCH 23
AXP 1.1	AXP 3.1	Pao Rosa 37 x 18	G	1	birchwood	
		Sucupira 37 x 18	G	1	birchwood	SCH 50
		Fiberglass 38 x 15	G	1	limewood	SCH 23
		Fiberglass 38 x 15	G	1	pinewood	SCH 11
		Rosewood 37 x 18	0 up to c <sup>#</sup> 2, F from d2	5	pinewood	SCH 16
TAKX 10	TAKX 30	Rosewood37 x 18	0 up to c <sup>#</sup> 2, G from d2	5	pinewood	SCH 16
		Palisono 38 x 15	0 up to c <sup>#</sup> 2, G from d2	4	pinewood	SCH 11
TAKX 100	TAKX 300	Palisono 38 x 15	0 up to c <sup>#</sup> 2, G from d2	4	pinewood	
		Palisono 38 x 15	0	3	pinewood	SCH 25
BKX 100	BKX 300	Palisono 38 x 15	0	3	pinewood	
		Rosewood 44 x 20	0	6	pinewood	SCH 25
GBKX 10	GBKX 30	Rosewood 44 x 20	0	6	pinewood	
		Palisono 44 x 20	0	6	pinewood	SCH 25
GBKX 100	GBKX 300	Palisono 44 x 20	0	6	pinewood	
		Pao Rosa 37 x 18	0 up to a, G from b⁵	6	birchwood	SCH 25
GBXP 1.1	GBXP 3.1	Pao Rosa 37 x 18	0 up to a, G from b⁵	4	birchwood	
		Sucupira 37 x 18	0 up to a, G from b⁵	6	birchwood	SCH 15
		Fiberglass 38 x 15	O up to a, G from b <sup>b</sup>	6	limewood	SCH 25
		Rosewood 37 x 15	0 up to c <sup>#</sup> 2, G from d2	38	RESOPHEN	SXY G 1
	1	Palisono 38 x 15	0 up to c <sup>#</sup> 2, G from d2	38	RESOPHEN	SXY G 1
000		6 1 26 12				CCILO
		Sucupira 36 x 18	G		pinewood	SCH 2
0	M		G = Fundamental Tuning 0 = Overtone Tuning	38 = 38 tuned RESOPHE	tube resonators made of N	



# Meisterklasse Metallophones

Meisterklasse metallophones have special alloy metal sound bars with overtone or fundamental tuning. All resonator boxes are equipped with brackets for carrying legs or the Basis Trolley system. All wood surfaces are protected with Proterra, an environmentally safe, all-natural varnish.

# Classroom Tip: Creating an ideal balance of mallet instruments for your ensemble

To properly equipt a classroom or ensemble, we recommend more xylophones (wood) than metallophones (metal) - the ideal ratio is 2:1. Xylophones have a shorter resonance and are suitable for playing melodies, while metallophones sustain longer and can overpower the ensemble with an improper ratio. With the right balance, metallophones provide good chordal accompaniment.

The tenor-alto models cover the tonal range of children's voices, so as the central voice, these instruments are ideal to purchase first and should be the largest quantity in your ensemble. Don't forget bass instruments as they create a harmonic foundation, while soprano instruments create melodic accents.



SKM 30s 23 bars, c2-b-flat3, 1 pair SCH 16, chromatic scale, combination of SKM 10 and SKM 20

### Tenor-Alto

TAKM 10 19 bars, c1-c3, 1 pair SCH 16, C-major scale with f-sharp1, b-flat1, f-sharp2 and b-flat2

**TAKM 20** 7 bars, sharp: c1, d1, g1, c2, d2, g2, c3, chromatic extension for TAKM 10

TAKM 30 26 bars, c1-c3, 1 pair SCH 16, chromatic scale, combination of TAKM 10 and TAKM 20

GBKM 10 16 bars, c-a1, 1 pair SCH 15, C-major scale with f-sharp, b-flat and f-sharp1

**GBKM 20** 6 bars, sharp: c, d, g, c1, d1, g1, chromatic extension for GBKM 10

**GBKM 30** 22 bars, c-a1, 1 pair SCH 15, chromatic scale combination of GBKM 10 and GBKM 20



Kristin Weimann, Product Manager Orff/Percussion,















20 | 21 METALLOPHONES

# Global Beat Metallophones

All Global Beat metallophones have 35 mm wide metal sound bars made of special alloy with overtone or fundamental tuning and resonator boxes made of birch plywood. Each metallophone is equipped with a carrying bag for 3 sound bars (2 x f-sharp, 1x b-flat).



# Concert Mallets

Sonor Concert Mallets are available with Palisono fiberglass, genuine, high-quality rosewood or alloy bars. One frame lets you change it up! Get a set of the rosewood bars and the alloy bars, and using the same frame, change your xylophone to a metallophone in minutes.



# proper places.

Frame	
CX CM	Frame construction with wheels, height adjustable from approx. 30 to 40 inches, resonator bar with
	tuned tube resonators made of shock-resistant RESOPHEN for 38 bars

Sound bar sets (56 pars, 1-1-sharps, chromatic scale)						
CX P 38	Rosewood sound bar set, 1 pair SCH SXY G 1, Rosewood bars 38 x 15 mm, overtone tuning up to c-sharp2, fundamental tuning from d2					
CX PO 38	Palisono sound bar set, 1 pair SCH SXY G 1, Palisono bars 38 x 15 mm, overtone tuning up to c-sharp2, fundamental tuning from d2					
CM L 38	Metal sound bar set, 1 pair SCH 16, Special alloy metal bars 40 x 6 mm, overtone tuning up to b, fundamental tuning from c1					
Complete Instruments						

CX P	Combination of CX CM and CX P 38
CX PO	Combination of CX CM and CX PO 38
CM L	Combination of CX CM and CM L 38





The SM and AM models have compact resonator boxes making them lighter weight and more portable. These are ideal for early childhood classes or mobile music therapists.

### Soprano

SM 13 bars, c2-f3, 1 pair SCH 17, C-major scale with f-sharp2 and b-flat2

### Alto

AM 16 bars, c1-a2, 1 pair SCH 5, C-major scale with f-sharp1, b-flat1 and f-sharp2







All wood surfaces are protected with Proterra, an environmentally safe, all-natural varnish.
(Euronorm EN 71-3)



ORFCAT18FULLV2 Sonor Orff Catalog.indd 21
















		Number of Bars	Scale	Tonal Range	
SOPRANO					
SKM 10	Soprano MEISTERKLASSE	16	C-major with f-sharp2, b-flat2 and f-sharp3	c2-a3	
SKM 20	Soprano MEISTERKLASSE	7		c#2, d#2, g#2, c#3, d#3, g#3, b <sup>b</sup> 3	
SMP 1.1	Soprano PRIMARY	16	C-major with f-sharp2, b-flat2 and f-sharp3	c2-a3	
SMP 2.1	Soprano PRIMARY	7		c#2, d#2, g#2, c#3, d#3, g#3, b <sup>b</sup> 3	
SM	Soprano Metallophone	13	C-major with f-sharp2 and b-flat2	c2-f3	
MS GB	Soprano GLOBAL BEAT	16	C-major with f-sharp2, b-flat2 and f-sharp3	c2-a3	
ALTO					
AMP 1.1	Alto PRIMARY	16	C-major with f-sharp1, b-flat1 and f-sharp2	c1-a2	
MP 2.1	Alto PRIMARY	7		c#1, d#1, g#1, c#2, d#2, g#2, bb2	
M	Alto Metallophone	16	C-major with f-sharp1, b-flat1 and f-sharp2	c1-a2	
ЛА GB	Alto GLOBAL BEAT	16	C-major with f-sharp1, b-flat1 and f-sharp2	c1-a2	
ENOR-ALTO					
AKM 10	Tenor-Alto MEISTERKLASSE	19	C-major with f-sharp1, b-flat1, f-sharp2 and b-flat2	c1-c3	
AKM 20	Tenor-Alto MEISTERKLASSE	7		c#1, d#1, g#1, c#2, d#2, g#2, c#3	
EEP BASS					
SBKM 10	Deep Bass MEISTERKLASSE	16	C-major with f-sharp, b-flat and f-sharp1	c-a1	
BKM 20	Deep Bass MEISTERKLASSE	6		c#, d#, g#, c#1, d#1, g#1	
GBMP 1.1	Deep Bass PRIMARY	16	C-major with f-sharp, b-flat and f-sharp1	c-a1	
GBMP 2.1	Deep Bass PRIMARY	7		c*, d*, g*, c*1, d*1, g*1, b <sup>b</sup> 1	
MGB GB	Deep Bass GLOBAL BEAT	16	C-major with f-sharp, b-flat and f-sharp1	c-a1	
M L	Concert Metallophone*	38	chromatic	f-f#3	





Primary Instrument	Full Chromatic Instrument	Bars (in mm)	Tuning	Resonator chambers	Resonator Material	Mallets (1 pair)
		38 x 10	G	3	pinewood	SCH 16
SKM 10	SKM 30	38 x 10	G	3	pinewood	
		35 x 5	G	1	birchwood	SCH 23
SMP 1.1	SMP 3.1	35 x 5	G	1	birchwood	
		30 x 4	G	1	pinewood	SCH 17
		35 x 5	G	1	birchwood	SCH 23
		35 x 5	G	1	birchwood	SCH 25
AMP 1.1	AMP 3.1	35 x 5	G	1	birchwood	
		40 x 6	G	1	pinewood	SCH 5
		35 x 5	G	1	birchwood	SCH 25
		38 x 10	0 up to h1, G from c2	5	pinewood	SCH 16
TAKM 10	TAKM 30	38 x 10	0 up to h1, G from c2	5	pinewood	
		45 x 13	0	6	pinewood	SCH 15
GBKM 10	GBKM 30	45 x 13	0	6	pinewood	
		35 x 10	O up to a, G from b <sup>b</sup>	6	birchwood	SCH 25
GBMP 1.1	GBMP 3.1	35 x 10	O up to a, G from b <sup>b</sup>	4	birchwood	
		35 x 10	O up to a, G from b <sup>b</sup>	6	birchwood	SCH 25
		40 x 6	0 up to h, G from c1	38	CX CM	SCH 16

 $\begin{aligned} \mathbf{G} &= \mathbf{Fundamental} \ \mathbf{Tuning} \\ \mathbf{0} &= \mathbf{Overtune} \ \mathbf{Tuning} \end{aligned}$ 

**38** = 38 tuned tube resonators made of RESOPHEN



The construction of metal bars requires balance of sound quality, timbre, sustain and volume, while eliminating side noises throughout several octaves.







# Meisterklasse Chime Bars

The Meisterklasse KS 50 L, KS 50 P, NKS 60 P and NKS 100 P have high-quality, genuine rosewood sound bars with overtone tuning and pinewood resonator boxes. All resonator boxes have tuning adjusters to change the sustain and volume. Special feet, developed by SONOR, provide for optimum resonance.

### Deep Bass

1 chime bar, 13 available chime bars: c, c-sharp, d, KS 50 P d-sharp, e, f, f-sharp, g,g-sharp, a, b-flat, b, c1


### **Contra Bass**

NKS 60 P 1 chime bar, 7 available chime bars: F, F-sharp, G, G-sharp, A, B-flat, B

# Sub-Contra Bass

NKS 100 P 1 chime bar, 5 available chime bars: C, C-sharp, D,

KS 400 P 3



# Rosewood bars 38 x 18 mm, fundamental tuning, resonators made of pinewood plywood

**KS 400 P** 1 chime bar, 26 available chime bars: c1, c-sharp1, d1, d-sharp1, e1, f1, f-sharp1, g1, g-sharp1, a1,b-flat1, b1, c2, c-sharp2, d2, d-sharp2, e2, f2, f-sharp2, g2, g-sharp2, a2, b-flat2, b2, c3, c-sharp3

KS 400 P1 19 chime bars, c1-c3, 1 pair SCH 16, C-major scale with f-sharp1, b-flat1, f-sharp2 and b-flat2

KS 400 P2 7 chime bars, sharp: c1, d1, g1, c2, d2, g2, c3, chromatic extension for KS 400 P1

KS 400 P3 26 chime bars, c1-cis3, 1 pair SCH 16, chromatic scale, combination of KS 400 P1 and KS 400 P2















# Meisterklasse Chime Bars

These chime bars provide excellent sound and craftsmanship, showing the quality of the instrument. Meisterklasse chime bars are available in the chromatic range of 5-octaves from C to c-sharp4.



# Tenor-Alto


Special alloy metal bars 40 x 6 mm, fundamental tuning, resonators made of shock-resistant RESOPHEN

- KS 40 L 1 chime bar, 26 available chime bars: c1, c-sharp1, d1, d-sharp1, e1, f1, f-sharp1, g1, g-sharp1, a1, b-flat1, b1, c2, c-sharp2, d2, d-sharp2, e2, f2, f-sharp2, g2, g-sharp2, a2, b-flat2, b2, c3, c-sharp3
- KS 40 L 1 19 chime bars, c1-c3, 1 pair SCH 5, C-major scale with f-sharp1, b-flat1, f-sharp2 and b-flat2
- KS 40 L 2  $\,$  7 chime bars, sharp: c1, d1, g1, c2, d2, g2, c3, chromatic extension for KS 40 L 1
- KS 40 L 3  $\,$  26 chime bars, c1-cis3, 1 pair SCH 5, chromatic scale, combination of KS 40 L 1 and KS 40 L 2  $\,$

### Soprano

Special alloy metal bars 30 x 4 mm, fundamental tuning, resonators made of shock-resistant RESOPHEN

- KS 30 L 1 chime bar, 26 available chime bars: c2, c-sharp2, d2, d-sharp2, e2, f2, f-sharp2, g2, g-sharp2, a2, b-flat2, b2, c3, c-sharp3, d3, d-sharp3, e3, f3, f-sharp3, g3, g-sharp3, a3, b-flat3, b3, c4, c-sharp4
- KS 30 L 1 19 chime bars, c2-c4, 1 pair SCH 3, C-major scale with f-sharp2, b-flat2, f-sharp3 and b-flat3
- KS 30 L 2 7 chime bars, sharp: c2, d2, g2, c3, d3, g3, c4, chromatic extension for KS 30 L 1
- KS 30 L 3 26 chime bars, c2-cis4, 1 pair SCH 3, chromatic scale, combination of KS 30 L 1 and KS 30 L 2







# Arrange notes as you wish!

No musical instrument is as versatile as chime bars. You can place chime bars in any order to suit your needs, and your own musical accompaniments. The design of the KS 40 L 15 SONOR Meisterklasse instrument set is particularly popular with children and educators alike. The notes of the C-major triad are marked with green dots and musical notes, the F-major triad notes in red, and the G-major triad notes in blue. Many songs can be played using these three chords, making chime bars the perfect accompaniment.



KS 40 L 15

For example the song: "My Bonnie lies over the Ocean"


My <sup>c</sup> Bonnie lies <sup>F</sup> over the <sup>c</sup> ocean,

My <sup>c</sup> Bonnie lies <sup>c</sup> over the <sup>G</sup> sea.

My C Bonnie lies F over the C ocean,

Please F bring back my G Bonnie to C me.

But aside from that, almost all accompaniments can be arranged using chime bars. Most children's songs can be played using 3 chords.





# Tenor-Alto

Special alloy metal bars 40 x 6 mm, fundamental tuning, resonators made of shock-resistant RESOPHEN

KS 40 L 15 15 chime bars, c1-c3, 8 pairs SCH 5, C-major scale, with instruction

The notes are played on the chime bars, with the three voices allocated to three players.




























# Reference Chime Bars

# Complete Sets

		Number of bars	Scale	Tonal range
SOPRANO				
KS 30 L 1	Soprano MEISTERKLASSE	19	C-major with f-sharp2, b-flat2, f-sharp3 and b-flat3	c2-c4
KS 30 L 2	Soprano MEISTERKLASSE	7		c#2, d#2, g#2, c#3, d#3, g#3, c#4
KSP 30 M 1	Soprano PRIMARY	19	C-major with f-sharp2, b-flat2, f-sharp3 and b-flat3	c2-c4
TENOR-ALTO				
KS 40 L 1	Tenor-Alto MEISTERKLASSE	19	C-major with f-sharp1, b-flat1, f-sharp2 and b-flat2	c1-c3
KS 40 L 2	Tenor-Alto MEISTERKLASSE	7		c*1, d*1, g*1, c*2, d*2, g*2, c*3
KS 40 L 15	Tenor-Alto MEISTERKLASSE	15	C-major	c1-c3
KS 40 L 1 BW	Tenor-Alto MEISTERKLASSE (Boomwhackers)	15	C-major	c1-c3
KS 400 P 1	Tenor-Alto MEISTERKLASSE	19	C-major with f-sharp1, b-flat1, f-sharp2 and b-flat2	c1-c3
KS 400 P 2	Tenor-Alto MEISTERKLASSE	7		c#1, d#1, g#1, c#2, d#2, g#2, c#3
KS 40 PO 1	Tenor-Alto PALISONO	19	C-major with f-sharp1, b-flat1, f-sharp2 and b-flat2	c1-c3
KS 40 PO 2	Tenor-Alto PALISONO	7		c#1, d#1, g#1, c#2, d#2, g#2, c#3
KSP 40 M 1	Tenor-Alto PRIMARY	19	C-major with f-sharp1, b-flat1, f-sharp2 and b-flat2	c1-c3
KSP 40 M 15	Tenor-Alto PRIMARY	15	C-major	c1-c3
KSP 40 X 1	Tenor-Alto PRIMARY	19	C-major with f-sharp1, b-flat1, f-sharp2 and b-flat2	c1-c3
DEEP BASS				
KSP 50 M 1	Deep Bass PRIMARY	10	C-major with f-sharp and b-flat	c-c1
KSP 50 X 1	Deep Bass PRIMARY	10	C-major with f-sharp and b-flat	c-c1


### Single Bars

Jiligic bars				
		Bars (in mm)	Tuning	Resonator Material
SOPRANO				
KS 30 L	Soprano MEISTERKLASSE	Metal 30 x 4	G	RESOPHEN
KSP 30 M	Soprano PRIMARY	Metal 30 x 4	G	RESOPHEN
TENOR-ALTO				
KS 40 L	Tenor-Alto MEISTERKLASSE	Metal 40 x 6	G	RESOPHEN
KS 40 L BW	Tenor-Alto MEISTERKLASSE (Boomwhackers)	Metal 40 x 6	G	RESOPHEN
KS 400 P	Tenor-Alto MEISTERKLASSE	Rosewood 37 x 18	G/0	Pinewood
KS 40 PO	Tenor-Alto PALISONO	Palisono 38 x 15	G/0	RESOPHEN
KSP 40 M	Tenor-Alto PRIMARY	Metal 35 x 5	G	RESOPHEN
KSP 40 X	Tenor-Alto PRIMARY	Pao Rosa 37 x 18	G	RESOPHEN
DEEP BASS				
KS 50 L	Deep Bass MEISTERKLASSE	Metal 45 x 13	0	Pinewood
KS 50 P	Deep Bass MEISTERKLASSE	Rosewood 44 x 20	0	Pinewood
KS 50 PO	Deep Bass PALISONO	Palisono 44 x 20	0	Pinewood
KSP 50 M	Deep Bass PRIMARY	Metal 38 x 10	0	Birchwood
KSP 50 X	Deep Bass PRIMARY	Pao Rosa 44 x 20	0	Birchwood
CONTRA BASS				
NKS 60 P	Contra Bass MEISTERKLASSE	Rosewood 53 x 20	0	Pinewood
NKS 60 PO	Contra Bass PALISONO	Palisono 53 x 20	0	Pinewood
KSP 60 X	Contra Bass PRIMARY	Pao Rosa 53 x 20	0	Birchwood
SUB-CONTRA BASS				
NKS 100 P	Sub-Contra Bass MEISTERKLASSE	Rosewood 100 x 20	0	Pinewood
NKS 100 PO	Sub-Contra Bass PALISONO	Palisono 100 x 20	0	Pinewood
KSP 100 X	Sub-Contra Bass PALISONO	Pao Rosa 100 x 20	0	Birchwood

G = Fundamental Tuning / O = Overtone Tuning







	Primary Instrument	Full Chromatic Instrument	Bars (in mm)	Tuning	Resonator Material	Mallets (1 pair)
			Metal 30 x 4	G	RESOPHEN	SCH 3
	KS 30 L 1	KS 30 L 3	Metal 30 x 4	G	RESOPHEN	
			Metal 30 x 4	G	RESOPHEN	SCH 3
			Metal 40 x 6	G	RESOPHEN	SCH 5
	KS 40 L 1	KS 40 L 3	Metal 40 x 6	G	RESOPHEN	
			Metal 40 x 6	G	RESOPHEN	SCH 5 (8 pair)
			Metal 40 x 6	G	RESOPHEN	SCH 23 (2 pair)
			Rosewood 37 x 18	G/0	Pinewood	SCH 16
	KS 400 P 1	KS 400 P 3	Rosewood 37 x 18	G/0	Pinewood	
			Palisono 38 x 15	G/0	RESOPHEN	SCH 11
	KS 40 PO 1	KS 40 PO 3	Palisono 38 x 15	G/0	RESOPHEN	
			Metal 35 x 5	G	RESOPHEN	SCH 5
			Metal 35 x 5	G	RESOPHEN	SCH 5 (8 pair)
			Pao Rosa 37 x 18	G	RESOPHEN	SCH 5
h						
			Metal 37 x 10	0	Birchwood	SCH 8
			Pao Rosa 44 x 20	0	Birchwood	SCH 8

22, ct2, d2, dt2, e2, f2, f2, g2, gt2, a2, bt2, b2, c3, c3, d3, d3, e3, e3, f3, g3, gt3, a3, bt3, b3, c4, ct4  23, d2, e2, f2, f2, g2, a2, bt2, b2, c3, d3, e3, f3, f3, g3, a3, bt3, b3, c4  24, ct1, ct1, d1, dt1, e1, f1, f1, g1, gt1, a1, bt1, b1, c2, ct2, d2, dt2, e2, f2, f2, g2, gt2, a2, bt2, b2, c3, ct3  25, ct1, ct1, d1, dt1, e1, f1, f1, g1, gt1, a1, bt1, b1, c2, ct2, d2, dt2, e2, f2, f2, g2, gt2, a2, bt2, b2, c3, ct3  26, ct1, ct1, d1, dt1, e1, f1, f1, g1, gt1, a1, bt1, b1, c2, ct2, d2, dt2, e2, f2, f2, g2, gt2, a2, bt2, b2, c3, ct3  27, ct1, d1, dt1, e1, f1, f1, g1, gt1, a1, bt1, b1, c2, ct2, d2, dt2, e2, f2, f2, g2, gt2, a2, bt2, b2, c3, ct3  28, f11  21, d1, e1, f1, f1, g1, g1, g1, a1, bt1, b1, c2, d2, e2, f2, f2, g2, a2, bt2, b2, c3  29, ct2, d1, e1, f1, f1, g1, a1, bt1, b1, c2, d2, e2, f2, f2, g2, a2, bt2, b2, c3  20, ct3, dt1, e1, f1, f1, g1, a1, bt1, b1, c2, d2, e2, f2, f2, g2, a2, bt2, b2, c3  21, ct1, d1, e1, f1, f1, g1, a1, bt2, b1, c2, d2, e2, f2, f2, g2, a2, bt2, b2, c3  21, ct2, dt2, e2, f2, f2, g2, a2, bt2, b2, c3  22, ct2, dt2, e2, f2, f2, g2, a2, bt2, b2, c3  23, ct3  24, ct2, ct2, ct2, ct2, ct2, ct2, ct2, ct2	Available bars	Recommended mallets
C, d2, e2, f2, f2, g2, a2, b2, b2, c3, d3, e3, f3, f3, g3, a3, b3, b3, c4  C1, c1, d1, d1, e1, f1, f1, g1, g1, a1, b1, b1, c2, c2, d2, d2, d2, e2, f2, f2, g2, g2, a2, b2, b2, c3, c3  C1, c1, d1, d1, e1, f1, f1, g1, g1, a1, b1, b1, c2, c2, d2, d2, d2, e2, f2, f2, g2, g2, a2, b2, b2, c3, c3  C1, c1, d1, d1, e1, f1, f1, g1, g1, a1, b1, b1, c2, c2, d2, d2, e2, f2, f2, g2, g2, a2, b2, b2, c3, c3  C1, c1, d1, e1, f1, f1, g1, a1, b1, b1, b1, c2, c2, d2, d2, e2, f2, f2, g2, g2, a2, b2, b2, c3, c3  C1, d1, e1, f1, f1, g1, a1, b1, b1, c2, d2, e2, f2, f2, g2, a2, b2, b2, c3  C2, d4, e1, f1, f1, g1, a1, b1, b1, c2, d2, e2, f2, f2, g2, a2, b2, b2, c3  C3, d1, e1, f1, f1, g1, a1, b1, b1, c2, d2, e2, f2, f2, g2, a2, b2, b2, c3  C4, d4, e1, f1, f1, g1, a1, b1, b1, c2, d2, e2, f2, f2, g2, a2, b2, b2, c3  C5, d4, e1, f1, f1, g1, a1, b1, b1, c2, d2, e2, f2, f2, g2, a2, b2, b2, c3  C5, d4, e1, f1, f1, g1, a1, b1, b1, c1  C5, d4, e1, f1, g1, a1, b1, b1, c1  C5, d4, e1, f1, g1, a1, b1, b1, c1  C5, d4, e1, f1, g1, a1, b1, b1, c1  C5, d5, d1, d1, d1, d1, d1, d1, d1, d1, d1, d1		
C1, c'1, d1, d'1, e1, f1, f1, g1, g¹, a1, b¹1, b1, c2, c'2, d2, d'2, e2, f2, f2, g2, g'2, a2, b²2, b2, c3, c'3  C1, c'1, d1, d'1, e1, f1, f1, g1, g¹1, a1, b¹1, b1, c2, c'2, d2, d'2, e2, f2, f2, g2, g'2, a2, b²2, b2, c3, c'3  C1, c'1, d1, d'1, e1, f1, f1, g1, g¹1, a1, b¹1, b1, c2, c'2, d2, d'2, e2, f2, f2, g2, g'2, a2, b²2, b2, c3, c'3  SCH 16  C1, c'1, d1, d'1, e1, f1, f1, g1, a1, b¹1, b1, c2, c'2, d2, d'2, e2, f2, f2, g2, g'2, a2, b²2, b2, c3  SCH 5  C1, d1, e1, f1, f1, g1, a1, b¹1, b1, c2, d2, e2, f2, f2, g2, a2, b²2, b2, c3  SCH 5  C1, d1, e1, f1, f1, g1, a1, b²1, b1, c2, d2, e2, f2, f2, g2, a2, b²2, b2, c3  SCH 5  C, c', d, d', e, f, f', g, g', a, b², b, c1  C, c', d, d', e, f, f', g, g', a, b², b, c1  C, d, e, f, f', g, a, b², b, c1  SCH 8, 15, 16  C, d, e, f, f', g, a, b², b, c1  SCH 8, 15, 16  C, d, e, f, f', g, a, b², b, c1  SCH 8, 15, 16  SCH 8  F, F', G, G', A, B², B  SCH 8  C, C', D, D², E	c2, c*2, d2, d*2, e2, f2, f*2, g2, g*2, a2, bb2, b2, c3, c*3, d3, d*3, e3, f3, f*3, g3, g*3, a3, bb3, b3, c4, c*4	SCH 3
61, 61, 61, 61, 61, 61, 61, 61, 61, 61,	c2, d2, e2, f2, f²2, g2, a2, b½2, b2, c3, d3, e3, f3, f³3, g3, a3, b⅓3, b3, c4	SCH 3
61, 61, 61, 61, 61, 61, 61, 61, 61, 61,		
C1, c1, d1, d1, e1, e1, f1, f1, g1, g1, a1, b1, b1, c2, c2, d2, d2, d2, e2, f2, f2, g2, g2, a2, b2, b2, c3, c3  SCH 16  C1, c1, d1, d1, e1, f1, f1, g1, a1, b1, b1, b1, c2, c2, d2, d2, d2, e2, f2, f2, g2, g2, g2, a2, b2, b2, c3, c3  SCH 5  C1, d1, e1, f1, f1, g1, a1, b1, b1, c2, d2, e2, f2, f2, g2, a2, b2, b2, b2, c3  SCH 5  C1, d1, e1, f1, f1, g1, a1, b1, b1, c2, d2, e2, f2, f2, g2, a2, b2, b2, c3  SCH 5  C, c1, d1, e1, f1, f1, g1, a1, b1, b1, c2, d2, e2, f2, f2, g2, a2, b2, b2, c3  SCH 5  C, c2, d, d3, e, f4, g, g3, a, b3, b, c1  SCH 8, 15, 16  C, c4, d, d4, e, f4, g, g4, a, b3, b, c1  SCH 8, 15, 16  C, d, e, f4, g, a, b3, b, c1  SCH 8, 15, 16	c1, c*1, d1, d*1, e1, f1, f*1, g1, g*1, a1, b\1, b1, c2, c*2, d2, d*2, e2, f2, f*2, g2, g*2, a2, b\2, b2, c3, c*3	SCH 5
C1, c²1, d1, d²1, e1, f1, f²1, g1, g²1, a1, b³1, b1, c2, c²2, d2, d²2, e2, f2, f²2, g2, g²2, a2, b³2, b2, c3  C1, d1, e1, f1, f²1, g1, a1, b³1, b1, c2, d2, e2, f2, f²2, g2, a2, b³2, b2, c3  C1, d1, e1, f1, f²1, g1, a1, b³1, b1, c2, d2, e2, f2, f²2, g2, a2, b³2, b2, c3  C1, d1, e1, f1, f²1, g1, a1, b³1, b1, c2, d2, e2, f2, f²2, g2, a2, b³2, b2, c3  C1, d1, e1, f1, f²1, g1, a1, b³1, b1, c2, d2, e2, f2, f²2, g2, a2, b³2, b2, c3  C1, d1, e1, f1, f²1, g1, a1, b³1, b1, c2, d2, e2, f2, f²2, g2, a2, b³2, b2, c3  C1, d1, e1, f1, f²1, g1, a1, b³1, b1, c2, d2, e2, f2, f²2, g2, a2, b³2, b2, c3  C1, d1, e1, f1, f²1, g1, a1, b³1, b1, c2, d2, e2, f2, f²2, g2, a2, b³2, b2, c3  C1, d1, e1, f1, f²1, g1, a1, b³1, b1, c2, d2, e2, f2, f²2, g2, a2, b³2, b2, c3  C1, d1, e1, f1, f²1, g1, a1, b³1, b1, c2, d2, e2, f2, f²2, g2, a2, b³2, b2, c3  C1, d1, e1, f1, f²1, g1, a1, b³1, b1, c2, d2, e2, f2, f²2, g2, a2, b³2, b2, c3  C1, d1, e1, f1, f²1, g1, a1, b³1, b1, c2, d2, e2, f2, f²2, g2, a2, b³2, b2, c3  C1, d1, e1, f1, f²1, g1, a1, b³1, b1, c2, d2, e2, f2, f²2, g2, a2, b³2, b2, c3  C1, d1, e1, f1, f²1, g1, a1, b³1, b1, c2, d2, e2, f2, f²2, g2, a2, b³2, b2, c3  C1, d1, e1, f1, f²1, g1, a1, b³1, b1, c2, d2, e2, f2, f²2, g2, a2, b³2, b2, c3  C1, d1, e1, f1, f²1, g1, a1, b³1, b1, c2, d2, e2, f2, f²2, g2, a2, b³2, b2, c3  C1, d1, e1, f1, f²1, g1, a1, b³1, b1, c2, d2, e2, f2, f²2, g2, a2, b³2, b2, c3  C1, d1, e1, f²1, f²1, g1, a1, b³1, b1, c2, d2, e2, f2, f²2, g2, a2, b³2, b2, c3  C1, d1, e1, f²1, f²1, g1, a1, b³1, b1, c2, d2, e2, f2, f²2, g2, a2, b³2, b2, c3  C1, d1, e1, f²1, f²1, g1, a1, b³1, b²1, c2, d2, e2, f2, f²2, g2, a2, b³2, b2, c3  C2, d2, d2, d2, d2, d2, d2, d2, d2, d2, d	ff1, bb1, ff2, bb2	SCH 23
C1, d1, e1, f1, f1, g1, a1, b <sup>a</sup> 1, b1, c2, d2, e2, f2, f <sup>a</sup> 2, g2, a2, b <sup>a</sup> 2, b2, c3  C1, d1, e1, f1, f <sup>a</sup> 1, g1, a1, b <sup>a</sup> 1, b1, c2, d2, e2, f2, f <sup>a</sup> 2, g2, a2, b <sup>a</sup> 2, b2, c3  C4, d1, e1, f1, f <sup>a</sup> 1, g1, a1, b <sup>a</sup> 1, b1, c2, d2, e2, f2, f <sup>a</sup> 2, g2, a2, b <sup>a</sup> 2, b2, c3  C5 C5 C6, d1, d1, e1, f1, f <sup>a</sup> 1, g1, a1, b <sup>a</sup> 1, b1, c2, d2, e2, f2, f <sup>a</sup> 2, g2, a2, b <sup>a</sup> 2, b2, c3  C5 C7, d1, d1, e1, f1, f <sup>a</sup> 1, g1, a1, b <sup>a</sup> 1, b1, c1  C7, c <sup>a</sup> 1, d1, d <sup>a</sup> 1, e1, f <sup>a</sup> 1, g1, a1, b <sup>a</sup> 1, b1, c1  C7, c <sup>a</sup> 1, d1, d <sup>a</sup> 1, e1, f <sup>a</sup> 1, g1, a1, b <sup>a</sup> 1, b1, c1  C7, c <sup>a</sup> 1, d1, d <sup>a</sup> 1, e1, f <sup>a</sup> 1, g1, a1, b <sup>a</sup> 1, b1, c1  C7, c <sup>a</sup> 1, d1, d <sup>a</sup> 1, e1, f <sup>a</sup> 1, g1, a1, b <sup>a</sup> 1, b1, c1  C7, c <sup>a</sup> 1, d1, d <sup>a</sup> 1, e1, f <sup>a</sup> 1, g1, a1, b <sup>a</sup> 1, b1, c1  C7, c <sup>a</sup> 1, d1, d <sup>a</sup> 1, e1, f <sup>a</sup> 1, g1, a1, b <sup>a</sup> 1, b1, c1  C7, c <sup>a</sup> 1, d1, d <sup>a</sup> 1, e1, f <sup>a</sup> 1, g1, a1, b <sup>a</sup> 1, b1, c1  C7, c <sup>a</sup> 1, d1, d <sup>a</sup> 1, e1, f <sup>a</sup> 1, g1, g <sup>a</sup> 1, a1, b <sup>a</sup> 1, b1, c1  C7, c <sup>a</sup> 1, d1, d <sup>a</sup> 1, e1, f <sup>a</sup> 1, g1, g <sup>a</sup> 1, a1, b <sup>a</sup> 1, b1, c1  C7, c <sup>a</sup> 1, d1, d <sup>a</sup> 1, e1, f <sup>a</sup> 1, g1, g1, g1, g1, g1, g1, g1, g1, g1, g	c1, c*1, d1, d*1, e1, f1, f*1, g1, g*1, a1, b\1, b1, c2, c*2, d2, d*2, e2, f2, f*2, g2, g*2, a2, b\2, b2, c3, c*3	SCH 16
C1, d1, e1, f1, f4, g1, a1, b4, b1, c2, d2, e2, f2, f42, g2, a2, b42, b2, c3       SCH 5         C, c4, d, d4, e, f, f4, g, g4, a, b4, b, c1       SCH 8, 15, 16         C, c4, d, d4, e, f, f4, g, g4, a, b4, b, c1       SCH 8, 15, 16         C, c4, d, d4, e, f, f4, g, g4, a, b4, b, c1       SCH 8, 15, 16         C, d, e, f, f4, g, a, b4, b, c1       SCH 8, 15, 16         C, d, e, f, f4, g, a, b4, b, c1       SCH 8, 15, 16         F, F4, G, G4, A, B4, B       SCH 8         F, F4, G, G4, A, B4, B       SCH 8         C, C4, D, D4, E       SCH 100	c1, c*1, d1, d*1, e1, f1, f*1, g1, g*1, a1, b\1, b1, c2, c*2, d2, d*2, e2, f2, f*2, g2, g*2, a2, b\2, b2, c3, c*3	SCH 11
c, c*, d, d*, e, f, f*, g, g*, a, bb, b, c1       SCH 8, 15, 16         c, c*, d, d*, e, f, f*, g, g*, a, bb, b, c1       SCH 8, 15, 16         c, c*, d, d*, e, f, f*, g, g*, a, bb, b, c1       SCH 8, 15, 16         c, d, e, f, f*, g, a, bb, b, c1       SCH 8, 15, 16         c, d, e, f, f*, g, a, bb, b, c1       SCH 8, 15, 16         F, F*, G, G*, A, Bb, B       SCH 8         F, F*, G, A, Bb, B       SCH 8         C, C*, D, D*, E       SCH 100	c1, d1, e1, f1, f⁴1, g1, a1, bʰ1, b1, c2, d2, e2, f2, f⁴2, g2, a2, bʰ2, b2, c3	SCH 5
C, C*, d, d*, e, f, f*, g, g*, a, bb, b, c1       SCH 8, 15, 16         C, C*, d, d*, e, f, f*, g, g*, a, bb, b, c1       SCH 8, 15, 16         C, d, e, f, f*, g, a, bb, b, c1       SCH 8, 15, 16         C, d, e, f, f*, g, a, bb, b, c1       SCH 8, 15, 16         F, F*, G, G*, A, Bb, B       SCH 8         F, F*, G, G*, A, Bb, B       SCH 8         C, C*, D, D*, E       SCH 100	c1, d1, e1, f1, f <sup>4</sup> 1, g1, a1, b <sup>b</sup> 1, b1, c2, d2, e2, f2, f <sup>4</sup> 2, g2, a2, b <sup>b</sup> 2, b2, c3	SCH 5
C, C*, d, d*, e, f, f*, g, g*, a, bb, b, c1       SCH 8, 15, 16         C, C*, d, d*, e, f, f*, g, g*, a, bb, b, c1       SCH 8, 15, 16         C, d, e, f, f*, g, a, bb, b, c1       SCH 8, 15, 16         C, d, e, f, f*, g, a, bb, b, c1       SCH 8, 15, 16         F, F*, G, G*, A, Bb, B       SCH 8         F, F*, G, G*, A, Bb, B       SCH 8         C, C*, D, D*, E       SCH 100		
C, C*, d, d*, e, f, f*, g, g*, a, bb, b, c1       SCH 8, 15, 16         C, d, e, f, f*, g, a, bb, b, c1       SCH 8, 15, 16         C, d, e, f, f*, g, a, bb, b, c1       SCH 8, 15, 16         F, F*, G, G*, A, Bb, B         F, F*, G, G*, A, Bb, B       SCH 8         F, F*, G, A, Bb, B       SCH 8         C, C*, D, D*, E       SCH 100	c, c*, d, d*, e, f, f*, g, g*, a, bʰ, b, c1	SCH 8, 15, 16
C, d, e, f, f*, g, a, bb, b, c1       SCH 8, 15, 16         C, d, e, f, f*, g, a, bb, b, c1       SCH 8, 15, 16         F, F*, G, G*, A, Bb, B       SCH 8         F, F*, G, A, Bb, B       SCH 8         C, C*, D, D*, E       SCH 100	c, c*, d, d*, e, f, f*, g, g*, a, bʰ, b, c1	SCH 8, 15, 16
C, d, e, f, f*, g, a, bb, b, c1       SCH 8, 15, 16         F, F*, G, G*, A, Bb, B       SCH 8         F, F*, G, A, Bb, B       SCH 8         C, C*, D, D*, E       SCH 100	c, c*, d, d*, e, f, f*, g, g*, a, bʰ, b, c1	SCH 8, 15, 16
F, F*, G, G*, A, Bb, B  F, F*, G, A, Bb, B  SCH 8  F, F*, G, A, Bb, B  SCH 8  SCH 8  SCH 100	c, d, e, f, f³, g, a, bʰ, b, c1	SCH 8, 15, 16
F, F*, G, G*, A, Bb, B  SCH 8  SCH 8  C, C*, D, D*, E	c, d, e, f, f³, g, a, bʰ, b, c1	SCH 8, 15, 16
F, F*, G, G*, A, Bb, B  SCH 8  SCH 8  C, C*, D, D*, E		
F, F*, G, A, B*, B  C, C*, D, D*, E  SCH 8	F, F*, G, G*, A, Bb, B	SCH 8
C, C*, D, D*, E	F, F*, G, G*, A, Bb, B	SCH 8
	F, F*, G, A, B <sup>b</sup> , B	SCH 8
	17 00 1	
C, C <sup>#</sup> , D, D <sup>#</sup> , E SCH 100	C, C*, D, D*, E	SCH 100
	C, C*, D, D*, E	SCH 100
C, D, E SCH 100	C, D, E	SCH 100



34|35 TONAL RANGES

# Tonal Ranges

In describing the complete range of SONOR Orff Instruments, we use standard voicing terms such as soprano, alto, and bass, and further define the complete tonal range for all instruments in the comprehensive tonal chart on the following page.

# Example:

The soprano xylophone SKX 300 has a chromatic scale from c2 to b-flat3 (23 notes).


The soprano glockenspiel NG 10 has a C-major scale with f-sharp3 and b-flat3 from c3 to f4 (13 notes).



Although the term "soprano" is used, neither tonal range nor scale are identical.


SONOR is using these terms only because they have become a standard in music literature worldwide. These instruments are transposing so care must be taken when used in a collaborative setting.





Concert Pitch a1 = 880 Oscillations = 440 Hz





means thinking today about the future and the music of tomorrow

with excellent sound but also to work according to our ecological and social responsibilities.

We continually seek to optimize operations, taking a variety of measures to steadily reduce emissions, waste and our demand for raw materials, as well as selecting raw materials as responsibly as possible.

As a company with its headquarters in Bad Berleburg-Aue, Germany, we place social responsibility at the core of our business philosophy. To us this means making a contribution to society and caring for our customers, employees and the German Siegen-Wittgenstein region.



#### **Energy and recycling**

The heating in our facilities is fueled by wood residue and pellets, probably

the simplest and most effective form of green energy generation. We hold ourselves and our facilities to the highest and most up-to-date standards, and our exhaust gas pollution is filtered in an environmentally friendly manner. The energy generated at our incineration plant heats our headquarters and other buildings. Starting in 2016, our entire electricity requirement will be obtained by green electricity, a trend-setting decision made for the good of the future. Climate protection and saving energy are not just issues facing the production side of our business. We insist on printing our marketing catalogs and flyers in a climate-neutral manner using certified printers.

It goes without saying that waste separation and recycling are key issues for us. As a matter of course, we reuse packaging several times in our dispatch department, in

order to avoid waste and to save on raw materials. Central to recycling are the packaging regulations, according to which we, as manufacturers, are required to collect, sort and process sales packaging, sent to private end consumers, in a dual system. This serves to avoid packaging waste and to ensure we reuse or reprocess these materials.

Our business environment was deliberately designed to be environmentally friendly. Have you ever heard of eco-plaster? This ecological, water-permeable surface material is used almost everywhere throughout our site. This permeable ground-covering material ensures the run-off of precipitation, so that the natural water cycle is not interrupted.

#### Responsible use of materials

We understand that trees are a vital component of our ecological balance. Because most of our instruments are made of wood, we are specially committed to ensuring that our raw materials come from responsibly managed sources.



As the first worldwide manufacturer to produce Orff instruments from certified woods, we earned our FSC™ certification in 2010.

The Forest Stewardship Council (FSC) is a non-profit independent organization of 43 countries. FSC's objective is to foster the responsible management of forests worldwide. It is supported

by environmental organizations and social associations such as WWF, Greenpeace, NAB, Robin Wood, IG BAU and IG Metall.

A key focus of the FSC is to give equal consideration to the social, ecological and economic aspects of the use of natural products. FSC certification offers the highest credibility for legal and exemplary forest management. We purchase imported wood exclusively from

suppliers who adhere to the worldwide standards of species protection to ensure that our imported wood supply conforms to both CITES<sup>1</sup> and EUTR<sup>2</sup>.



We use reconstructed veneers alongside natural ones. Our reconstructed veneers are produced by Alpi, a company based in Italy. Alpi's ecologic strategy is to use farmed wood and controlled forestry to achieve a sparing use of natural

 $resources \ - completely \ in \ harmony \ with \ our \ environment.$ 

Since 2004, we have used Proterra, an ecological finish, on the surfaces of our wood products. Proterra is produced from shellac, oil, and carnauba wax. Instead of a lacquer-based wood stain, we insist on using a water-soluble, environmentally friendly stain. We do this not just for environmental reasons, but also to protect the health of our staff and customers around the world.

#### Responsibility to society, our employees and the region

As a manufacturer of musical instruments, it is our mission to help foster an active music-making society by supporting projects, initiatives and associations that work in tandem with our vision. For that reason, we sponsor up to 50 seminars that offer music education



training for teachers,
preschool teachers, as well
as other school, preschools
and social facilities staff
members. The future of
our company is ensured by
means of targeted training

and continued education in various fields. Fair working conditions, occupational safety, human resources policies based on differing phases of life, and remunerating our staff in line with negotiated contracts, all of this is a matter of course for our business.

Integral to our business philosophy is the strengthening and safe-guarding of our company's site at Bad Berleburg-Aue., Germany.

Securing the future of the site of our headquarters is also part of supporting the region in which it is based.

Whenever possible, we involve regional suppliers and service companies, support cultural events and work together with social facilities.



<sup>1</sup> CITES (Convention on International Trade in Endangered Species of Wild Flora and Fauna) is a treaty that aims to regulate the international trade in wild animals and plants to the extent that the survival of animal and plant species living in the wild are not endangered.

<sup>2</sup> The EU Timber Regulation (EUTR) seeks to prevent the sale of illegally sourced wood within the European Union. It prohibits the import of wood and wood products from illegal logging into the EU domestic market.







40 | 41 PERCUSSION


### Timpani

Suitable mallets are: SCH 6, SCH 7, SCH 8 or SCH 60

V 1554

#### Meisterklasse Rotary Timpani

Since 1821, rotary kettle drums have been used in orchestral settings. For over 140 years, SONOR has adapted these drums for the education market integrating a proven system of central tuning. The technical advantage of the SONOR timpani lies in the unimpeded transfer of vibration from the head to the shell.



### Meisterklasse Rotary Timpani with calfskin heads and three stand legs

V 1570 10" (25 cm), tonal range approx. C - a
V 1571 13" (33 cm), tonal range approx. G - e
V 1573 16" (40 cm), tonal range approx. E - c

18" (46 cm), tonal range approx. C – G





Original calfskin


System of central tuning

#### Meisterklasse Screw Adjustment Timpani

The easiest and most traditional type of timpani tuning mechanism is the tension screw system. By turning 5 to 8 tension screws (depending on the diameter of the timpani) to the right, the head is tightened and the pitch increased. If the tension screws are turned to the left, the head is loosened and the pitch becomes lower.

### Meisterklasse Screw Adjustment Timpani with calfskin heads and three stand legs

V 1551 13" (33 cm), tonal range approx. G - e
V 1553 16" (40 cm), tonal range approx. E - c
V 1554 18" (46 cm), tonal range approx. C - G







V 1551

V 1553

with plastic heads and three stand legs

TP 13 13" (33 cm), tonal range approx. G - e

**TP** 16 16" (40 cm), tonal range approx. E – c



#### **Primary Screw Adjustment Timpani**

These timpani can also be used as timbales or tom toms.

The unique shape of the hoops and the durable plastic heads allow for dynamic playing with a variety of implements, including drum sticks. Unlike natural skin heads, these plastic heads are resistant to changes in pitch caused by fluctuations in humidity. This allows Primary timpani to sound great in a variety of conditions.





### Did you know?

Timpani are instruments with a specific range of pitch that can be fine tuned to individual notes. They arrived in Europe from Arabia in a reduced form during the 13th century. From the 17th century onwards, the timpani gained in significance within orchestral music. Carl Orff developed a school timpani for his Orff Schulwerk with a wooden cylinder, open below, instead of a semi-spherical kettle. Since the 1950s, these timpani have been a key component of the SONOR-Orff program.









SONOR Hand Drums are made according to high quality standards in a wide variety of designs and dimensions.

Hand Drums are available either with select natural skins or plastic heads for different sound characters and playing techniques. Natural skins offer a warmer tone, plastic heads sound dryer and react less sensitive to temperature changes.



#### Hand drums with tunable natural skins, beechwood frames with natural lacquer finish, nickel-plated tension hoops

LHDN 10	25 cm (10"), 5 tension rods
LHDN 13	33 cm (13"), 6 tension rods
LHDN 14	36 cm (14"), 7 tension rods
LHDN 16	40 cm (16"), 8 tension rods

#### Hand drums with tunable plastic heads, beechwood frames with natural lacquer finish, nickel-plated tension hoops

LHDP 10	25 cm (10"), 5 tension rods
LHDP 13	33 cm (13"), 6 tension rods
LHDP 14	36 cm (14"). 7 tension rods

### Hand drums with tunable natural skin and beater

CG THD 8 N	20 cm (8")
CG THD 10 N	25 cm (10")
CC TUD 12 N	20 cm (12")

### Hand drums with tunable plastic head and beater

CG THD 8 P	20 cm (8")
CG THD 10 P	25 cm (10")
CG THD 12 P	30 cm (12")

#### Hand drums with pre-tuned natural skin

mana arams	With pre tunea natural skin
CG HD 8 N	20 cm (8"), beater
CG HD 10 N	25 cm (10"), beater
HDP	Primary Hand drum 20 cm (8") with practical handle on the inside
ТВ	Toy Sound Drum-bear 20 cm (8")



42 | 43 PERCUSSION

### Tambourines











**CGT 10 N** 

Tambourines with tunable plastic head, nickel silver jingles, beechwood frames with natural lacquer finish, nickel-plated tension hoops

LTA 20 25 cm (10"), 5 tension rods, 20 pair of jingles LTA 6 25 cm (10"), 5 tension rods,

6 pair of jingles CGTT8P 20 cm (8"), 7 tension rods, 6 pair of jingles

**CG TT 10 P** 25 cm (10"), 10 tension rods, 9 pair of jingles

**CG TT 12 P** 30 cm (12"), 11 tension rods, 20 pair of jingles

#### Tambourines with pre-tuned natural skin

CGT6N 15 cm (6"), 5 pair of jingles CGT8N 20 cm (8"), 7 pair of jingles CG T 10 N 25 cm (10"), 9 pair of jingles

LHT



CG HD 10N

#### Instruments with Jingles

LHT Tambourine 25 cm (10"), 20 pairs of nickel silver jingles, beechwood frame with

natural lacquer finish

CGHT 10 D Tambourine 25 cm (10"), 18 pairs of jingles Tambourine 30 cm (12"), 20 pairs of jingles Tambourine Star 25 cm (10"), GTS

14 pairs of jingles, star-shaped, colored

#### Tambourine with an ergonomically shaped handle

TBBJ Tambourine, black with brass jingles TBSJ Tambourine, black with steel jingles TWBJ Tambourine, white with brass jingles TWSJ Tambourine, white with steel jingles




























46 | 47 PERCUSSION

### Wood Percussion



Wood idiophones are a large group of instruments coming from different cultures. They are used for basic rhythm patterns or for complex challenging playing styles. Like the originals, SONOR wood percussion instruments are carefully handmade from select hardwoods. They have great sound quality and a cutting, powerful projection.





LTU

Claves	
CLA	Claves, Cuban design
LCL 1	Claves, 22 mm, rosewood
LCL 2	Claves, 17 mm, rosewood
LCL 3	Claves, 27 mm, rosewood, original Mexican model
PCI	Primary Claves heachwood 1 nair



They have an excellent cutting sound with high projection.




GTB Tone Block, length 20 cm, with beater
GDTB S Double Tone Block, 3.5 cm, with beater
GDTB M Double Tone Block, 4.5 cm, with beater











# JT SONOR® be unique

#### 48 | 49 PERCUSSION



Chico

CAJS CB

Body made from MDF, 2 playing surfaces made of birch, equipped with 12 snare wires, two-color body, 32 x 25 x 30 cm (HxWxD)

## Cajons for Children

#### Two playing surfaces!

Children often have difficulty playing on a regular sized cajon because their feet can't touch the floor. To address this, SONOR specially developed two children-sized cajons for kids to play.



The Chico, our smallest cajon is especially suited for children at the elementary school level, while







#### Mediano

CAJS MC

Body made from MDF, 2 playing surfaces made of birchwood, equipped with 12 steel snare wires, two-color body, 40,5 x 29.5 x 29.5 cm (HxWxD)



#### 2-in 1-Tip:

Because of their double function as an instrument and a seat, cajons are suitable chair substitutes in your music room!

Primero Cajon Pad

These small and portable pads can easily be played on your lap or held between your knees like a bongo. All models include snare wires and produce an authentic cajon sound, though at lower volumes. Due to a special surface treatment additional sound effects can be created such as wind noise or rain.

The foam rubber provides a stable, comfortable playing surface. Attractive pricing and space-saving design make this instrument an popular choice for groups and classrooms.



Typical cajon sound with reduced volume, space-saving, portable, ideal practice pad

Primero Cajon Pad

CAJ PAD PB

Made of MDF (medium density fiberboard ) and HDF (high density foam), equipped with 12 steel strand snare wire, 2.5 x 29.5 x 29.5 cm (HxWxD)

CAJ PAD PB Primero Cajon Pad black
CAJ PAD PW Primero Cajon Pad white



#### **Build Your Own Individual Cajon!**

It's fun to build your own cajon with our DIY - "Do It Yourself" - Cajon set. All parts are precisely prefabricated, so children can quickly and easily assemble their cajon and learn crafting skills. An ideal team project for music, woodworking, and art classes. High quality wood material and snare wire elements contribute to this Cajon's great sound. Includes all tools and materials needed for assembly plus detailed instructions and templates. Tips for playing and sample first lesson also included in assembly guide. After construction, the DIY Cajon can be colored, stamped, printed, oiled, waxed or lacquered. There are no bounds to your creativity!

#### DIY Cajon

Main plates made of gabon wood, front plate made of birch, snare system includes: snare wire, screwdriver, wood glue and sand paper

CAJS DIY K Do it Yourself Cajon Kids, measurements of the assembled Cajon: 33 x 29.5 x 29.5 cm (HxWxD)

CAJS DIY A Do it Yourself Cajon Adults, measurements of the assembled Cajon: 45 x 29.5 x 29.5 cm (HxWxD)






**CAJ PAD PW** 





50 51 ACCESSORIES

# Mallets



	Mallet Application	Mallet Name	Head Material	Mallet Hardness	Mallet Shaft
SCH 40	Glockenspiels	Wooden headed mallet	wood	hard	wood
SCH 95	Glockenspiels	Wooden headed mallet	wood	hard	plastic
SCH 1	Glockenspiels	Rubber headed mallet	rubber	soft	plastic
SCH 2	Glockenspiels	Rubber headed mallet	rubber	medium hard	plastic
SCH 3	Glockenspiels	Rubber headed mallet	rubber	hard	plastic
SCH 13	Glockenspiels	Double mallet	wood and rubber	hard	plastic
SCH 109	Glockenspiels, Soprano Instruments	Glockenspiel mallet	glass	hard	plastic
SCH 17	Glockenspiels, Soprano Instruments	Felt headed mallet	felt	hard	plastic
SCH 16	Soprano / Tenor-Alto Instruments	Concert mallet	woolen yarn	hard	plastic
SCH 5	Soprano / Tenor-Alto Instruments	Felt headed mallet	felt	medium hard	plastic
SCH 23	Soprano / Tenor-Alto Instruments	Felt headed mallet	felt	hard	plastic
SCH 50	Soprano / Tenor-Alto Instruments	Felt headed mallet	felt	hard	plastic
SCH 11	Soprano / Tenor-Alto Instruments, Palisono	Felt ring mallet	felt ring with wood core	medium hard	plastic
SCH 6	Bass Instruments, Timpani	Wool felt headed mallet	wool felt	soft	plastic
SCH 15	Bass and Deep Bass Instruments	Concert mallet	wool yarn	medium hard	plastic
SCH 25	Bass and Deep Bass Instruments	Concert mallet	wool yarn	medium hard	plastic
SCH 60	Deep Bass instruments, Timpani	Wool felt headed mallet	wool felt	medium hard	tonkin
SCH 8	Deep Bass instruments, Timpani	Wool felt headed mallet	wool felt	soft	tonkin
SCH 100	Contra Bass and Sub-Contra Bass Instruments	Contra Bass mallet	wool felt	soft	tonkin







**(** 

	Mallet Application	Mallet Name	Head Material	Mallet Hardness	Mallet Shaft
SXY G 1	Xylophone, Professional	Xylophone mallet	rubber	soft	tonkin
SXY H 2	Xylophone, Professional	Xylophone mallet	rosewood	hard	tonkin
SXY H 3	Xylophone, Professional	Xylophone mallet	rosewood	hard	wood
SXY H 4	Xylophone, Professional	Xylophone mallet	wood with leather cover	hard	wood
STI 20	Timpani, Drums, Cymbals	Junior Timpani mallet	felt	hard	wood
STI 21	Timpani, Drums, Cymbals	Junior Timpani mallet	felt	medium hard	wood
STI 22	Timpani, Drums, Cymbals	Junior Timpani mallet	felt	medium hard	wood
STI 23	Timpani, Drums, Cymbals	Junior Timpani mallet	felt	soft	wood
STI 26	Timpani, Drums, Cymbals	Junior Timpani mallet	felt	soft	wood
STIF 24	Timpani, Drums, Cymbals	Junior Timpani mallet	flannel	hard	wood
STIF 25	Timpani, Drums, Cymbals	Junior Timpani mallet	flannel	medium hard	wood
STI H 7	Timpani, Professional	Timpani mallet	felt with wood core	hard	tonkin
STIH9	Timpani, Professional	Timpani mallet	felt with wood core	medium hard	tonkin
STI K 2	Timpani, Professional	Timpani mallet	felt with cork core	hard	tonkin
STI K 4	Timpani, Professional	Timpani mallet	felt with cork core	medium hard	tonkin
SCH 7	Hand Drums, Cymbals	Felt headed mallet	felt	soft	plastic
SCH 40	Wood Percussion, Small Hand Drums	Wood headed mallet	wood	hard	wood
SCH 95	Wood Percussion	Wood headed mallet	wood	hard	plastic





52|53 ACCESSORIES

## BasisTrolley

#### **Basis Trolley System**

The SONOR Basis Trolley is very popular due to its versatile usage with larger SONOR instruments. The frame features caster wheels on a wide leg system that allow for ease-of-transportation and resonator box protection. Additional adapters are required to use the Basis Trolley.

Please note: Adapters that are listed below (AD1,2, AC1, 2) must be specified and included when ordering a Basis Trolley. The BT will not function without the corresponding adapter.

#### **Basis Trolley**

Basis Trolley, height and width adjustable trolley with 4 large, smooth running wheels

#### **Basis Trolley Adapters**

- Adapter for Basis Trolley and diatonic soprano, alto tenor-alto and bass mallet instruments with 3 brackets, 1 rail 166 mm, 1 rail 300 mm, 3 adapters, 1 assembly key
- Adapter for Basis Trolley and diatonic deep bass mallet instruments, SSX and ShortScale Xylophone with 4 brackets, 1 rail 166 mm, 1 rail 300 mm, 4 adapters, 1 assembly key
- Adapter for Basis Trolley and chromatic soprano, alto, tenor-alto and bass mallet instruments with 3 brackets, 1 rail 300 mm, 1 rail 572 mm, 6 adapters, 1 assembly key
- AC 2 Adapter for Basis Trolley and chromatic extensions for deep bass mallet instruments with 4 brackets, 2 rails 300 mm, 4 adapters, 1 assembly key



# Stand Leg

Stand Leg, height-adjustable, for screwing into brackets of box resonators, instrument cases and timpani







Bracket

Depending on your instrument, you will need 3 or 4 legs per instrument. Simply count the number of mounting plates on your resonator boxes!



5/2/18 09:41







# Parts

However, throughout their use, bars can get lost, flexible pins might break, and tubing may need to be replaced. Maintaining part consistency allows us to







#### **Sound Bar Holders**

ZG 1	for GP, NG, white, 10 pieces
ZG 2	for SG, TAG, black, 10 pieces
ZG 3	for SGL, TAGL, black, 10 pieces, (not shown)
ZS 1	for all xylophones and metallophones with box resonator, 10 pieces
ZS 2	for Global beat fiberglass xylophones, 10 pieces
Z KS 30 N	for KS 30, KSP 30, KSP 30 M, white, 2 pieces
Z KS 40 N	for KS 40, KSP 40, KSP 40 M & X, white, 2 pieces
Z KS 400	for KS 400, black, 2 pieces
Z KS 50	for KS 50, KSP 50, KSP 50 M & X, black, 2 pieces
Z KS 60	for NKS 60, KSP 60 X, black, 1 piece
Z KS 100	for NKS 100, KSP 100 X, black, 1 piece
ZR 1	for CX, CM, BSX 300, black, 1 piece



#### **Pin Strips and Felt Strips** Pin strip for SGP, AGP, GS GB, GA GB, black, 2 pieces, incl. felt strip ZB 1

ZB 2	Pin strip for SG, GS, BWG, black, 2 pieces, incl. felt strip
ZB 3	Pin strip for MG, black, 2 pieces, incl. felt strip
ZB 4	Pin strip for GSM, GAM, black, 2 pieces, incl. felt strip
FB 1	Felt strip for SG, GS, BWG, white
FB 2	Felt strip for SGP, AGP, GS GB, GA GB, white
FB 3	Felt strip for MG, white
FB 4	Felt strip for GSM, GAM, white
ALS 1	Rubber cording (1 meter) for all metallophon and xylophones

#### **Hand Drum Tension Rods**

803 003 19 for Latino Hand Drums 998 506 00 for Global Hand Drums

#### **Feet and Brackets**

F KS 2	Feet for NKS 100, rubber, 4 pieces
F KSP	Feet for KSP 50, KSP 60, KSP 100, plastic, 4 pieces
F CAJ	Feet for Cajons, all models
762 212 59	Bracket, complete for box resonator instruments and timpani
765 164 59	Adapter, for Basis Trolley rails

Feet for KS 50, NKS 60, rubber, 4 pieces

#### **Natural Skins unmounted**

700 005 35	Natural skin, 35 cm
700 005 43	Natural skin, 43 cm
700 005 46	Natural skin, 46 cm
700 005 50	Natural skin, 50 cm
700 005 56	Natural skin, 56 cm
700 005 61	Natural skin, 61 cm

#### **Natural Skins mounted**


733 007 71	Natural skin, 10" for LHDN 10 (V 1619/163
733 009 71	Natural skin, 13" for LHDN 13 (V 1620)
733 011 71	Natural skin, 14" for LHDN 14 (V 1621)
733 012 71	Natural skin, 16" for LHDN 16 (V 1622)
733 008 71	Natural skin, 10" for V 1550/1570
733 010 71	Natural skin, 13" for V 1551/1571
733 013 71	Natural skin, 16" for V 1553/1573
733 014 71	Natural skin, 18" for V 1554/1574

/33 011 / 1	Natural Skill, 14 TOT LITDIN 14 (V TOZT)
733 012 71	Natural skin, 16" for LHDN 16 (V 1622)
733 008 71	Natural skin, 10" for V 1550/1570
733 010 71	Natural skin, 13" for V 1551/1571
733 013 71	Natural skin, 16" for V 1553/1573
733 014 71	Natural skin, 18" for V 1554/1574
Jingles and	Bells
NSS	Nickel silver jingles for PJS, LTA, LHT, V 4002, 1 pair
762 016 02	Bell for V 4001, with rivet
762 017 02	Bell for V 4003, with loop
762 021 02	Bell, single, small, for V 4004
762 022 02	Bell, single, medium, for V 4004
762 023 02	Bell, single, large, for V 4004
762 007 01	Leather strap for cymbals V 3900, V 3901, V 3902, PHC
762 028 01	Leather strap for hanging cymbals V 2012, V 2014



56 | 57

# Index



N .		"
Accessories53	Circle Effect43	Hand Bells44
Agogo Bell44	Claves	Hand Drum41-42
Alto Glockenspiel7-9	Concert Metallophone20-21	Hanging Cymbal45
Alto Metallophone18-21	Concert Xylophone20-21	
Alto Xylophone12-15	Cowbell44	J
	Cymbals45	Jinglestick44
В		
Bags 54	D	ι
Basis Trolley	Deep Bass Metallophone18-20	Leg 52
Bar Chimes	Deep Bass Xylophone12-15	
Bass Xylophone12-15	DIY Cajon49	M
Boomwhackers® Glockenspiel	Drum Bear41	Mallets50-51
Boomwhackers® Chime Bars		Mouse Glockenspiel9
Brass Cowbells44	F	Meisterklasse
	Finger Cymbals45	Metallophone18-21
C	Fiberglass Chime Bars	Music Stand53
Cabasa		
Castanets	G	N
Cajons48-49	Global Beat5, 7, 14-15, 21	Natural Skin55
Cajon Pad	Glockenspiel6-9	
Cajon Bags	Glockenspiel Bags53	F
Chime Bars24-31	Guiro43	
















S



P	
Palisono	4
Palisono Sound Bar	13, 20
Pao Rosa Sound Bar	5, 14-15, 27
Parts	54-55
Primary	5, 7, 14-15, 19, 27, 30, 40
Q	
Quijada	43
R	
Rosewood Sound Bar	4, 12, 20, 24
Rotary Timpani	40
1	

Screw Adjustment Timpani		
Shekere		
Sleigh Bells44		
Solid Bar Chimes45		
SONOR Stick Bag53		
Soprano Glockenspiel6-9		
Soprano Metallophone18-21		
Soprano Xylophone12-15		
Sound Bar Bags53		
Steel Sound Bar6-9		
Strap53		
Sucupira Sound Bar5, 12, 14		
Sustainability36-37		

Tambourines
Temple Blocks
Tenor-Alto Glockenspiel
Tenor-Alto Metallophone
Tenor-Alto Xylophone
Timpani
Tone Block
Tonal Range
Triangle
W
Walking-Xylophone
Wood Block


.....42

.....18-19

.....12-13

.....46 .....34-35





Wooden Agogo.....



